



## Installation, Operation and Maintenance Manual

---

### LQ Series

Portable Chillers  
7 to 40 Tons

---

*Page intentionally blank*

# Table of Contents

---

<b>Foreword</b> .....	<b>1</b>
<b>Installation</b> .....	<b>1</b>
Receiving Inspection .....	1
Rigging, Handling, and Locating Equipment .....	1
Electrical Power .....	1
Table 1 - Voltage Utilization Range .....	2
Water Cooled Condenser Water Lines .....	2
Table 2 - Condenser Water Flow Requirements .....	3
Air Cooled Chillers Condenser Air .....	3
Chilled Water Lines.....	3
Table 3 - LQ Series Chilled Water Flow Requirements.....	3
Figure 1 - Recommended Overhead Piping .....	4
Remote Air Cooled Condenser Interconnecting Refrigerant Piping.....	4
<b>Start-Up</b> .....	<b>5</b>
Table 4 – Required Ethylene Glycol Solutions (% Glycol by Weight) .....	5
Table 5 - Required Propylene Glycol Solutions (% Glycol by Weight).....	6
<b>Controler Operation</b> .....	<b>8</b>
Table 6 - Microprocessor Control Fault Logic .....	8
Power.....	8
Start .....	9
Stop.....	9
Alarm Reset .....	9
Alarm Silence .....	9
Lower Set Point Temperature .....	9
Raise Set Point Temperature .....	9
No Flow.....	9
High Refrigerant Pressure.....	9
Low Refrigerant Pressure .....	10
Freezestat .....	10
Low Oil Pressure .....	10
Over Set Point.....	10
Under Set Point .....	10
Pump On .....	10
Compressor On.....	10
Partial Load.....	10
Water Make-Up .....	11
Low Water Level .....	11
High Water Temperature .....	11
Probe Fault .....	11
Changing Temperature Display Scale .....	11
Diagnostic Error Codes .....	13
Table 7 - Diagnostic Error Codes .....	13
<b>Control Options</b> .....	<b>14</b>
Return Water Temperature Display .....	14
Remote On/Off Contacts .....	14
Remote Alarm Contacts.....	14
Alarm Horn .....	14
Remote Control Panel .....	14
SPI Communications .....	14
Table 8 - SPI Baud Rate Adjustment.....	15
<b>Chiller Operation</b> .....	<b>15</b>
Coolant Circuit .....	15
Refrigerant Circuit .....	15

<b>Chiller Construction .....</b>	<b>16</b>
Compressor.....	16
Air Cooled Condenser .....	16
Water Cooled Condenser .....	16
Condenser Water Regulating Valve.....	16
Condenser Remote Air-Cooled .....	16
Evaporator .....	17
Thermostatic Expansion Valve.....	17
Refrigerant Sight Glass .....	17
Refrigerant Filter Drier.....	17
Pressure Relief Valve .....	17
Hot Gas Bypass Valve .....	17
Reservoir.....	18
Coolant Pump .....	18
Pressure Gauge.....	18
Y-Strainer .....	18
Fan Cycling Controls .....	18
High Refrigerant Pressure Switch .....	18
Low Refrigerant Pressure Switch.....	18
High Refrigerant Temperature Switch.....	18
Freezestat .....	18
Coolant Flow Switch .....	19
Automatic Water Make-Up (Optional) .....	19
Upgraded Pumps (Optional).....	19
<b>Preventive Maintenance.....</b>	<b>19</b>
Once a Week.....	19
Once a Month.....	20
Every Three Months .....	20
<b>Preventive Maintenance Checklist.....</b>	<b>21</b>
<b>Troubleshooting.....</b>	<b>22</b>
<b>Charts &amp; Pump Curves .....</b>	<b>23</b>
Table 9 - LQ2A08 & LQ2B08 Electrical Specifications .....	23
Table 10 - LQ2A10 & LQ2B10 Electrical Specifications .....	24
Table 11 - LQ2A14 & LQ2B14 Electrical Specifications .....	25
Table 12 - LQ2A15 & LQ2B15 Electrical Specifications .....	26
Table 13 - LQ2A20 & LQ2B20 Electrical Specifications .....	27
Table 14 - LQ2A25 & LQ2B25 Electrical Specifications .....	28
Table 15 - LQ2W08, LQ2R08, LQ2W10 & LQ2R10 Electrical Specifications .....	29
Table 16 - LQ2W15, LQ2R15, LW2W20 & LQ2R20 Electrical Specifications .....	30
Table 17 - LQ2W25, LQ2R25, LQ2W30, LQ2R30, LQ2W35, LQ2R35, LQ2W40 & LQ2R40 Electrical Specification .....	31
Figure 2 - 60 Hz Pump Curves .....	32
<b>Drawings.....</b>	<b>33</b>
Figure 3 - LQ2B Series Suggested Ductwork Diagram .....	33
<b>Warranty .....</b>	<b>34</b>

## Foreword

---

The intent of this manual is to serve as a guide for placing your portable chiller in service and operating and maintaining it properly. This manual is supplemented as required to accommodate any special items that may have been provided for a specific application. The written information contained in this manual, as well as various drawings, are intended to be general in nature. The schematics included in this manual are typical only. Actual schematics are included in the electrical enclosure of the chiller and should be referred to for troubleshooting and servicing of the unit. Additional copies of wiring diagrams are available upon request. We strive to maintain an accurate record of all equipment during the course of its useful life. While every effort is made to standardize the design features of these chillers, the various options may make it necessary to rearrange some of the components; therefore, some of the general drawings in this manual may differ from your specific unit.

Specific references to current applicable codes, ordinances, and other local laws pertaining to the use and operation of this equipment are avoided due to their ever-changing nature. There is no substitute for common sense and good operating practices when placing any mechanical equipment into operation. We encourage all personnel to familiarize themselves with this manual's contents. Failure to do so may unnecessarily prolong equipment down time.

The chilling equipment uses chemical refrigerants for heat transfer purposes. This chemical is sealed and tested in a pressurized system containing ASME coded vessels; however, refrigerant gas can be released if there is a system failure. Refrigerant gas can cause toxic fumes if it is exposed to fire. These units must be placed in a well-ventilated area, especially if open flames are present.

Failure to follow these instructions could result in a hazardous condition. Consult the unit serial tag for information about the refrigerant type and charge amount. Customers are advised to immediately implement a refrigerant management program including a survey of all equipment to document the type and quantity of refrigerant in each machine. All refrigeration service technicians must be certified by an EPA approved organization. It is recommended that good piping practices are followed and that the information in this manual is adhered to. We cannot be held responsible for liabilities created by substandard piping methods and installation practices external to the chiller.

We trust your equipment will have a long and useful life. If you should have any questions, please contact our Customer Service Department specifying the serial number and model number of the unit as indicated on the nameplate.

## Installation

---

### Receiving Inspection

Each unit is skid mounted and boxed or crated to protect it during shipping. If the chiller has a remote air-cooled condenser, the chiller and the condenser will ship skid mounted and will contain a holding charge of nitrogen. Before accepting delivery, check the box or crate for visible damage. If damage is evident, it should be properly documented on the delivery receipt and the box or crate should be immediately removed to allow for detailed inspection of the unit. Check for broken refrigerant lines, oil leaks, damaged controls, or any other major component torn loose from its mounting point. Any sign of damage should be recorded and a claim filed immediately with the shipping company. In order to expedite payment for damages it is important to record and document damage. An excellent way to do this is by taking pictures. Our Customer Service Department will provide assistance with the preparation and filing of your claims, including arranging for an estimate and quotation on repairs.

### Rigging, Handling, and Locating Equipment

The units have a welded steel tube frame that has been designed to allow the unit to be positioned with a forklift. Proper rigging methods must be followed to prevent damage to components. Avoid impact loading caused by sudden jerking when lifting or lowering the chiller. Use pads where abrasive surface contact is anticipated.

The unit is designed for indoor use. If it is necessary to store the chiller in an unheated area when not in use, be sure that all water is drained or that an adequate amount of antifreeze is added to prevent freeze-up of the unit. A primary concern when designing your unit was serviceability, therefore, the chiller should be located in an accessible area.

### Electrical Power

All wiring must comply with local codes and the National Electric Code. Minimum circuit ampacities and other unit electrical data are on the unit nameplate and are shown in the Electrical Specification section at the back of this manual. A specific

electrical schematic is shipped with the unit. Measure each leg of the main power supply voltage at the main power source. Voltage must be within the voltage utilization range given in Table 1.

**Table 1 - Voltage Utilization Range**

Rated Voltage	Utilization Range
230	208 to 254
460	414 to 506
575	516 to 633

If the measured voltage on any leg is not within the specified range, notify the supplier and correct before operating the unit. Voltage imbalance must not exceed two percent. Excessive voltage imbalance between the phases of a three-phase system can cause motors to overheat and eventually fail. Voltage imbalance is determined using the following calculations:

$$\% \text{ Imbalance} = (V_{\text{avg}} - V_x) \times 100 / V_{\text{avg}}$$

$$V_{\text{avg}} = (V_1 + V_2 + V_3) / 3$$

$V_x$  = phase with greatest difference from  $V_{\text{avg}}$

For example, if the three measured voltages were 442, 460, and 454 volts, the average would be:

$$(442 + 460 + 454) / 3 = 452$$

The percentage of imbalance is then:

$$(452 - 442) \times 100 / 452 = 2.2 \%$$

This exceeds the maximum allowable of 2%.

A terminal block is provided for main power connection to the main power source. The main power source should be connected to the terminal block through an appropriate disconnect switch. A separate lug for grounding the unit is also provided in the main control panel. Electrical phase sequence must be checked at installation and prior to start-up. Operation of the compressor with incorrect electrical phase sequencing will result in mechanical damage to the compressors. The phasing must be checked with a phase sequence meter prior to applying power. The proper sequence should read "ABC" on the meter. If the meter reads "CBA", open the main power disconnect and switch two line leads on the line power terminal blocks (or the unit mounted disconnect). All components requiring electric power are wired in-phase at the factory. Do not interchange any load leads that are from the unit contactors or the motor terminals.



**WARNING:** It is imperative that L1-L2-L3 are connected in the A-B-C phase sequence to prevent equipment damage due to reverse rotation.



**CAUTION:** The unit requires the main power to remain connected during off-hours to energize the compressor's crankcase heater. Disconnect main power only when servicing the chiller. The crankcase heater should remain on when the compressor is off to ensure liquid refrigerant does not accumulate in the compressor crankcase.



**WARNING:** The control panel and safeties are wired such that connecting the appropriate power source to the main terminal block energizes the entire electric circuitry of the chiller. A control transformer has been factory wired to step down the incoming power to the 115-volt control power. Electric power at the main disconnect should be shut off before opening access panels for repair or maintenance. The unit must be properly grounded in compliance with local and national codes.

## Water Cooled Condenser Water Lines

The performance of the condenser is dependent on maintaining the proper flow and temperature of water through the heat exchanger. Insufficient water flow or high condenser water supply temperatures will result in the reduction of cooling capacity of the chiller. Extreme conditions will eventually result in the chiller shutting down due to high refrigerant pressure. Performance can be adversely affected if the condenser is allowed to plug up from contaminants in the condenser water stream. In order to reduce maintenance costs and chiller downtime, a water treatment program is highly recommended for the condenser cooling water. If any condenser does become plugged, contact our Customer Service Department for assistance in the proper procedure for cleaning out the condenser.

The standard cooling capacity is based upon 85°F (29°C) condenser cooling water supply. Under normal operating conditions there will be a 10°F (6°C) rise through the condenser resulting in 95°F (35°C) exiting water temperature from the condenser. To ensure proper water flow through the condenser, the condenser water pump should be able to handle up to 25 PSI (1.75 Kg/cm<sup>2</sup>) pressure drop through the condenser. While the design pressure loss is much lower than 25 PSI (1.75 Kg/cm<sup>2</sup>), we recommend the pumping system be sized for this loss to ensure there will be sufficient supply pressure to the condensers. To prevent damage to the condenser or regulating valve, the condenser water pressure should not exceed 150 PSIG (10.5 Kg/cm<sup>2</sup>). The condenser water regulating valve controls the condenser water flow. The chiller loading and condenser water inlet temperature will determine the actual flow. Table 2 shows minimum condenser water flow requirements for the different size chillers at different supply temperatures.

**Table 2 - Condenser Water Flow Requirements**

Model Number	GPM (L/min) @ 70°F (21°C)	GPM (L/min) @ 75°F (24°C)	GPM (L/min) @ 80°F (27°C)	GPM (L/min) @ 85°F (29°C)	GPM (L/min) @ 90°F (32°C)
LQ2W08	8 (29)	9 (35)	12 (46)	17 (64)	26 (97)
LQ2W10	12 (46)	15 (56)	19 (74)	27 (102)	41 (153)
LQ2W15	18 (70)	23 (85)	30 (112)	41 (155)	62 (233)
LQ2W20	26 (97)	31 (119)	41 (155)	57 (216)	86 (324)
LQ2W25	32 (119)	39 (146)	50 (191)	70 (265)	105 (397)
LQ2W30	37 (140)	45 (171)	59 (223)	82 (310)	123 (466)
LQ2W35	44 (167)	54 (205)	71 (269)	98 (371)	148 (561)
LQ2W40	52 (197)	62 (235)	82 (311)	114 (432)	172 (652)

The minimum flows are determined using the condenser water regulating valve setting of 210 PSI for a given supply temperature. The supply temperature range is from 70°F (24°C) to 90°F (32°C). Supply temperatures beyond this range are not recommended and may lead to improper chiller operation.

### Air Cooled Chillers Condenser Air

In order to accommodate the air-cooled condenser, the chiller must be located in a well-ventilated area. A minimum of three feet of clearance is required at both the condenser air inlet and condenser air discharge. Improper clearance or poor ventilation will reduce the cooling capacity of the chiller and may cause high refrigerant pressure problems. The condenser air inlet temperature should be maintained above 60°F (15°C) in order to avoid possible low refrigerant pressure safety trips during start-up.

### Chilled Water Lines


All chilled water piping should be adequately insulated to prevent condensation. If water is allowed to condense on the piping, the state change of the water from gas to liquid will result in a substantial heat load that becomes an additional burden for the chiller. Standard portable chillers have been designed to provide 50°F (10°C) coolant to the process. Under normal operating conditions there will be a 10°F (6°C) rise through the process resulting in 60°F (16°C) return coolant temperature to the chiller.

**Table 3 - LQ Series Chilled Water Flow Requirements**

Model	Nominal Flow GPM (L/min)	Pressure Drop PSI (Kg/cm <sup>2</sup> )
LQ2A08/LQ2B08	17 (64)	6.0 (0.42)
LQ2A10/LQ2B10	24 (91)	6.2 (0.44)
LQ2A14/LQ2B14	33 (124)	5.4 (0.38)
LQ2A15/LQ2B15	36 (136)	Call
LQ2A20/LQ2B20	48 (182)	Call
LQ2A25/LQ2B25	56 (212)	Call
LQ2W08/LQ2R08	18 (68)	6.0 (0.42)
LQ2W10/LQ2R10	25 (95)	6.2 (0.44)
LQ2W15/LQ2R15	39 (148)	5.4 (0.38)
LQ2W20/LQ2R20	51 (193)	Call
LQ2W25/LQ2R25	63 (239)	Call
LQ2W30/LQ2R30	75 (284)	Call
LQ2W35/LQ2R35	84 (318)	Call
LQ2W40/LQ2R40	96 (364)	Call

The importance of properly sized piping between the chiller and process cannot be overemphasized. See the ASHRAE Handbook or other suitable design guide for proper pipe sizing. In general, run full size piping out to the process and then reduce the pipe size to match the connections on the process equipment. One of the most common causes of unsatisfactory chiller performance is poorly designed piping. Avoid unnecessarily long lengths of hoses or quick disconnect fittings that offer high resistance to water flow. When manifolds are required for water distribution, they should be installed as close to the use point as possible. Provide flow-balancing valves at each machine to assure adequate water distribution in the entire system. The connection labeled “Chilled Water Supply” delivers fluid to the process and the connection labeled “Chilled Water Return” receives water back from the process. Typically when piping is overhead with a total run length over 90 feet (27 M) there should be a valve in the supply line and an inverted P trap with a vacuum break valve installed as shown in Figure 1.

**Figure 1 - Recommended Overhead Piping**



### Remote Air Cooled Condenser Interconnecting Refrigerant Piping

Remote air cooled condenser chillers ship with a nitrogen holding charge and has a full charge of oil, excluding the additional charge for field piping. Proper evacuation is required prior to charging with refrigerant. The chiller is for use only with the air-cooled condenser provided with the unit. The following section covers the required piping between the chiller and the provided air-cooled condenser.

Caps are located on the discharge and liquid lines. These line sizes do not necessarily reflect the actual line sizes required for the piping between the chiller and the air-cooled condenser. The installing contractor need only provide the interconnecting piping between the chiller and the air-cooled condenser.

Refrigerant piping size and piping design has a significant effect on system performance and reliability. For specific pipe sizing and configuration, refer to the LQR Series Chiller Remote Air Cooled Condenser Installation Guidelines Manual. All piping should conform to the applicable local and state codes. Use refrigerant grade copper tubing only and isolate the refrigeration lines from building structures to prevent transfer of vibration. Do not use a saw to remove end caps. This might allow copper chips to contaminate the system. Use a tube cutter or heat to remove the caps. When sweating copper joints it is important to flow dry nitrogen through the system. This prevents scale formation. Do not use soft solders. For copper-to-copper joints use a phos-copper solder with 6% to 8% silver content. Use a high silver content brazing rod for copper-to-brass or copper-to-steel joints. Only use oxy-acetylene brazing.

# Start-Up

Every unit is factory set to deliver chilled water in accordance with the standard operating specifications for that particular chiller. Due to variables involved with different applications and different installations, minor adjustments may be required during the initial start-up to ensure proper operation. The following start-up procedure should be followed in sequence. If trouble is encountered during start-up, the fault can usually be traced to one of the control or safety devices. This outline can be used as a checklist for the initial start-up and for subsequent start-ups if the chiller is taken out of service for a prolonged period of time.

1. Assure the main power source is connected properly, that it matches the voltage shown on the nameplate of the unit, and that it is within the voltage utilization range given in Table 1. Electrical phase sequence must be checked at installation and prior to start-up. Operation of the compressor with incorrect electrical phase sequencing will result in mechanical damage to the compressors. The phasing must be checked with a phase sequence meter prior to applying power. The proper sequence should read “ABC” on the meter. If the meter reads “CBA”, open the main power disconnect and switch two line leads on the line power terminal blocks (or the unit mounted disconnect). All components requiring electric power are wired in-phase at the factory. Do not interchange any load leads that are from the unit contactors or the motor terminals. Once proper power connection and grounding have been confirmed, turn the main power on.



**WARNING:** It is imperative that L1-L2-L3 are connected in the A-B-C phase sequence to prevent equipment damage due to reverse rotation.

**Note:** The main power must be on for 24 hours prior to starting the compressor to allow the crankcase heater to sufficiently vaporize any liquid refrigerant that may be present in the compressor.

2. Check to make sure that all process chilled water piping connections are secure. Open the cabinet and fill the chilled water reservoir with the proper water or water/glycol solution. Use glycol with a corrosion inhibitor only. See Table 4 and Table 5 for recommended glycol solutions.

**Table 4 – Required Ethylene Glycol Solutions (% Glycol by Weight)**

		Coldest Ambient Condition Chiller Exposed To												
		40°F (4°C)	35°F (2°C)	30°F (-1°C)	25°F (-4°C)	20°F (-7°C)	15°F (-9°C)	10°F (-12°C)	5°F (-15°C)	0°F (-18°C)	-5°F (-21°C)	-10°F (-23°C)	-15°F (-26°C)	-20°F (-29°C)
Chiller Set Point	80°F (27°C)	0%	0%	5%	15%	20%	25%	30%	35%	35%	40%	45%	45%	50%
	75°F (24°C)	0%	0%	5%	15%	20%	25%	30%	35%	35%	40%	45%	45%	50%
	70°F (21°C)	0%	0%	5%	15%	20%	25%	30%	35%	35%	40%	45%	45%	50%
	65°F (18°C)	0%	0%	5%	15%	20%	25%	30%	35%	35%	40%	45%	45%	50%
	60°F (16°C)	0%	0%	5%	15%	20%	25%	30%	35%	35%	40%	45%	45%	50%
	55°F (13°C)	0%	0%	5%	15%	20%	25%	30%	35%	35%	40%	45%	45%	50%
	50°F (10°C)	0%	0%	5%	15%	20%	25%	30%	35%	35%	40%	45%	45%	50%
	45°F (7°C)	0%	0%	5%	15%	20%	25%	30%	35%	35%	40%	45%	45%	50%
	40°F (4°C)	5%	5%	5%	15%	20%	25%	30%	35%	35%	40%	45%	45%	50%
	35°F (2°C)	15%	15%	15%	15%	20%	25%	30%	35%	35%	40%	45%	45%	50%
	30°F (-1°C)	20%	20%	20%	20%	20%	25%	30%	35%	35%	40%	45%	45%	50%
	25°F (-4°C)	25%	25%	25%	25%	25%	25%	30%	35%	35%	40%	45%	45%	50%
	20°F (-7°C)	30%	30%	30%	30%	30%	30%	30%	35%	35%	40%	45%	45%	50%
	15°F (-9°C)	35%	35%	35%	35%	35%	35%	35%	35%	35%	40%	45%	45%	50%
	10°F (-12°C)	35%	35%	35%	35%	35%	35%	35%	35%	35%	40%	45%	45%	50%
5°F (-15°C)	40%	40%	40%	40%	40%	40%	40%	40%	40%	40%	45%	45%	50%	
0°F (-18°C)	45%	45%	45%	45%	45%	45%	45%	45%	45%	45%	45%	45%	50%	

**Table 5 - Required Propylene Glycol Solutions (% Glycol by Weight)**

		Coldest Ambient Condition Chiller Exposed To												
		40°F (4°C)	35°F (2°C)	30°F (-1°C)	25°F (-4°C)	20°F (-7°C)	15°F (-9°C)	10°F (-12°C)	5°F (-15°C)	0°F (-18°C)	-5°F (-21°C)	-10°F (-23°C)	-15°F (-26°C)	-20°F (-29°C)
Chiller Set Point	80°F (27°C)	0%	0%	10%	15%	20%	25%	30%	35%	40%	40%	45%	45%	50%
	75°F (24°C)	0%	0%	10%	15%	20%	25%	30%	35%	40%	40%	45%	45%	50%
	70°F (21°C)	0%	0%	10%	15%	20%	25%	30%	35%	40%	40%	45%	45%	50%
	65°F (18°C)	0%	0%	10%	15%	20%	25%	30%	35%	40%	40%	45%	45%	50%
	60°F (16°C)	0%	0%	10%	15%	20%	25%	30%	35%	40%	40%	45%	45%	50%
	55°F (13°C)	0%	0%	10%	15%	20%	25%	30%	35%	40%	40%	45%	45%	50%
	50°F (10°C)	0%	0%	10%	15%	20%	25%	30%	35%	40%	40%	45%	45%	50%
	45°F (7°C)	0%	0%	10%	15%	20%	25%	30%	35%	40%	40%	45%	45%	50%
	40°F (4°C)	10%	10%	10%	15%	20%	25%	30%	35%	40%	40%	45%	45%	50%
	35°F (2°C)	15%	15%	15%	15%	20%	25%	30%	35%	40%	40%	45%	45%	50%
	30°F (-1°C)	20%	20%	20%	20%	20%	25%	30%	35%	40%	40%	45%	45%	50%
	25°F (-4°C)	25%	25%	25%	25%	25%	25%	30%	35%	40%	40%	45%	45%	50%
	20°F (-7°C)	30%	30%	30%	30%	30%	30%	30%	35%	40%	40%	45%	45%	50%
	15°F (-9°C)	35%	35%	35%	35%	35%	35%	35%	35%	40%	40%	45%	45%	50%
	10°F (-12°C)	40%	40%	40%	40%	40%	40%	40%	40%	40%	40%	45%	45%	50%
5°F (-15°C)	40%	40%	40%	40%	40%	40%	40%	40%	40%	40%	45%	45%	50%	
0°F (-18°C)	45%	45%	45%	45%	45%	45%	45%	45%	45%	45%	45%	45%	50%	

3. (LQ2W08 – LQ2W40 only) Check the condenser water lines to make sure all connections are secure. Make sure sufficient condenser water flow and pressure are available, the condenser water supply is turned on, and all shut-off valves are opened
4. (LQR Models Only) Check the refrigerant lines to make sure all connections are secure and that a proper evacuation of the chiller, the field piping, and the remote condenser has occurred.
5. Charge the chiller with refrigerant. For LQR chillers, please refer to the LQR Series Chiller Remote Air-Cooled Condenser Installation Guidelines Manual to determine the required refrigerant charge. LQA and LQW chillers come factory charged and should require no additional refrigerant.
6. (LQR Models Only) Check the remote condenser main power and control wiring to ensure all connections are secure.
7. Verify that all refrigerant valves are open.
8. Make sure the Freezestat is set appropriately for the operating conditions of the chiller. The Freezestat is located inside the main electrical control panel. It should be set at 10°F (5°C) below the minimum chilled water temperature setting that the chiller will be operating. Reference Table 4 to be sure the coolant solution has sufficient freeze protection (glycol) to handle at least 5°F (2.8°C) below the Freezestat setting. All chillers are shipped from the factory with the Freezestat set at 38°F (3°C). This is done to protect against a possible freeze-up if no glycol has been added to the coolant. Once the proper glycol solution has been added, the Freezestat can be adjusted to the appropriate setting.

**Note: The manufacturer's warranty does not cover the evaporator from freezing. It is vital that the Freezestat is set properly.**

9. Turn on the control power by turning the Power button to "On". The panel displays should now be illuminated.
10. Due to extreme ambient temperatures that the unit may be exposed to during shipment, the High Refrigerant Pressure switch may have tripped. If this is the case, disconnect the main power and reset the High Refrigerant Pressure by depressing the manual reset button located on the switch. Reconnect the main power and turn the control power on by pressing the Power button. Clear the alarm condition by pressing the Alarm Reset button.
11. Establish flow through the evaporator. Standard units are provided with an internal pump that can be energized by pressing the Start button. If the unit has been customized and does not have an internal pump, the external pump should be energized to establish flow through the evaporator.

**Note: The compressor will not start as long as the flow switch is open. A positive flow must be established through the evaporator before the compressor can operate.**

12. Set water flow through the evaporator as indicated in Table 3 using a discharge throttling valve or flow control valve (by others). The valve should be the same size as the To Process connection of the chiller. A significant increase in flow

beyond the recommended rate may damage the evaporator and create excessive pressure drops that influence the overall efficiency of the system.

13. Set the desired leaving water temperature on the control panel using the Up and Down buttons. The chiller should now be controlling to the selected temperature. Please note that if there is insufficient load the compressor may cycle on and off causing swings in temperature.



**WARNING:** Under no circumstance should the High Refrigerant Pressure or the Low Compressor Pressure switch be deactivated. Failure to heed this warning can cause serious compressor damage, severe personal injury or death.


14. Regulation of the chiller temperature is based on return water temperature. Unless otherwise specified, it is factory set to deliver coolant at 50°F (10°C). Adjust to the desired operating temperature. Resetting the temperature will change the operating conditions of the chiller. Any lower readjustment of the controller must be done only after referencing Table 4 to ensure that the coolant has adequate antifreeze protection.
15. Operate the system for approximately 30 minutes. Check the liquid line sight glass. The refrigerant flow past the sight glass should be clear. Bubbles in the refrigerant indicate either low refrigerant charge or excessive pressure drop in the liquid line. A shortage of refrigerant is indicated if operating pressures are low and subcooling is low. Normal subcooling ranges are from 10°F (5.5°F) to 20°F (11°C). If subcooling is not within this range, check the superheat and adjust if required. The superheat should be approximately 10°F (5.5°C). Since the unit is factory charged, adding or removing refrigerant charge should not be necessary. If the operating pressures, sight glass, superheat, and subcooling readings indicate a refrigerant shortage, gas-charge refrigerant as required. With the unit running, add refrigerant vapor by connecting the charging line to the suction service valve and charging through the backseat port until operating conditions become normal.



**CAUTION:** A clear sight glass alone does not mean that the system is properly charged. Also check system superheat, subcooling, and unit operating pressures. If both suction and discharge pressures are low but subcooling is normal, a problem other than refrigerant shortage exists. Do not add refrigerant, as this may result in overcharging the circuit.

Once proper flow and temperature are achieved, press the Stop button. The unit is now ready to be placed into service.

# Controller Operation



The chiller includes a microprocessor controller designed to perform all control functions directly from the front panel. When a button is depressed, a click will be felt and the corresponding LED will be energized. Only one button should be pressed at a time. Table 6 shows the basic control fault logic for the microprocessor controller.

**Table 6 - Microprocessor Control Fault Logic**

Fault	Alarm Indication	Compressor Shutdown	Pump Shut Off	Alarm Reset Required <sup>1</sup>	Manual Reset Required <sup>2</sup>	Remote Alarm Activated <sup>3</sup>
No Flow	LED	Yes	Yes	No	No	Yes
High Refrigerant Pressure	LED	Yes	Yes	Yes	Yes	Yes
Low Refrigerant Pressure	LED	Yes	No	Yes	No	Yes
Freezestat	LED	Yes	No	Yes	No	Yes
Low Oil Pressure	LED	Yes	Yes	Yes	Yes	Yes
Over Set Point	LED	No	No	No	No	Yes
Under Set Point	LED	Yes	No	Yes	No	Yes
Low Water Level	LED	No	No	No	No	No
High Water Temperature	LED	No	No	No	No	No
Probe Fault	LED	Yes	Yes	Yes	No	Yes
Low Power	Pr OFF	Yes	Yes	Yes	No	Yes
Pump Overload	Err 126	Yes	Yes	Yes	Yes	Yes
Compressor Overload	Err 127	Yes	Yes	Yes	No	Yes
High Temperature Safety	Err 128	Yes	Yes	Yes	No	Yes

<sup>1</sup> Alarm Reset button or Stop button on control panel must be pressed.

<sup>2</sup> Safety control must be manually reset before the controller can be reset.

<sup>3</sup> Activates the alarm horn (if included) and closes the alarm contact (if included).

## Power

Depressing the Power button will switch the control power on or off. Control power must be initiated before either the Start button or remote on/off contacts can start the chiller.

## Start



Depressing the Start button will start the pump and enable the compressor. The compressor (and condenser fans or blowers if the chiller is air cooled) will start only if the microprocessor is calling for cooling because the actual To Process temperature is higher than the Set Point temperature.

*Note: Once the compressor has cycled off, it will not restart for 2.5 minutes because of an internal anti-cycle time delay.*

## Stop



Depressing the Stop button will shut off the compressor, pump, condenser fans or blowers (if the chiller is air cooled), and clear all fault signals.

## Alarm Reset



Depressing the Alarm Reset button will reset any fault indicator that has been activated on the control board. This includes any LED indicators or alarm codes. The High Refrigerant Pressure, Low Oil Pressure, and Pump Overload require a mechanical safety to be manually reset before the control board can be reset.

*Note: If the condition still exists that originally caused the alarm indication, the alarm may be reactivated as soon as it is reset.*

## Alarm Silence



The Alarm Silence button is only functional if the Alarm Horn option and/or Remote Alarm Contact option has been purchased. If the Alarm Horn option has been purchased, depressing the Alarm Silence button will disable the horn. The horn will not reactivate until the alarm has been reset and a subsequent alarm has been triggered. If the Remote Alarm contacts option has been purchased, depressing the Alarm Silence button will open the contact that was closed when the alarm occurred. The contact will not close again until the alarm has been reset and a subsequent alarm has been triggered.

## Lower Set Point Temperature



Each time the Lower Set Point Temperature button is depressed and released the Set Point temperature will decreased by 1°F (or 1°C). If the Lower Set Point Temperature button is held down, the Set Point temperature will continue to decrease until the button is released.

## Raise Set Point Temperature



Each time the Raise Set Point Temperature button is depressed and released the Set Point temperature will increased by 1°F (or 1°C). If the Raise Set Point Temperature button is held down, the Set Point temperature will continue to increase until the button is released.

## No Flow



The No Flow LED will be illuminated if the flow through the chiller is below the preset acceptable level. When the Start button is depressed, this safety is defeated for a period of 20 seconds in order for the pump to establish flow. The No Flow LED may remain illuminated during this 20 second period. This safety will shut off the pump and the compressor. If the chiller has been shut down by the No Flow safety, the Start button must be depressed in order to restart the pump and reset the 20 second time delay.

## High Refrigerant Pressure



If the compressor discharge refrigerant pressure exceeds the setting on the high refrigerant pressure safety, the compressor and pump will shut off and the High Refrigerant Pressure LED will be illuminated. Pressing the Alarm Reset button will reset the High Refrigerant Pressure fault, as long as the High Refrigerant Pressure switch located at the discharge of the compressor has been manually reset.

## Low Refrigerant Pressure



If the compressor suction pressure drops below the setting on the low refrigerant pressure safety, the compressor will shut off, the pump will remain running, and the Low Refrigerant Pressure LED will be illuminated. Pressing the Alarm Reset button will reset the Low Refrigerant Pressure fault, as long as the refrigerant pressure has risen back up above the safety's cutout level.

## Freezestat



If the coolant temperature being delivered to the process drops below the setting on the Freezestat, the compressor will shut off, the pump will remain running, and the Freezestat LED will be illuminated. The Freezestat should be set 10°F (5°C) above the freezing point of the glycol solution and 10°F (5°C) below the minimum operating temperature. The Freezestat is factory set at 38°F (3°C). In order to reset the Freezestat fault press the Alarm Reset button after resetting the mechanical thermostat (labeled Freezestat) inside the electrical enclosure.

## Low Oil Pressure



This LED is nonfunctional on standard units and will be activated only if the unit has been modified to include a low oil pressure sensor (typical for semi-hermetic reciprocating compressor units). If the unit has a low oil pressure sensor and the oil pressure in the compressor crankcase drops below the factory set level on the oil pressure switch, the compressor and pump will shut off, and the Low Oil Pressure LED will be illuminated. In order to reset the Low Oil Pressure fault, press the Alarm Reset button after resetting the mechanical pressure switch located inside of the cabinet near the Compressor.

## Over Set Point



The Over Set Point LED will be illuminated if the To Process temperature exceeds the Set Point temperature by more than 5°F (3°C). This fault causes only an alarm indication (horn and/or remote contact) and the chiller will continue to operate. Although the Over Set Point LED will turn on immediately whenever the temperature is out of range, the alarm relay is disabled for 30 minutes after start-up or after a change in set point. The alarm will automatically clear when the To Process temperature is no more that 5°F (3°C) above the Set Point temperature.

## Under Set Point



The Under Set Point LED will be illuminated if the To Process temperature drops below the Set Point temperature by more than 10°F (5°C). This fault will shut off the compressor, but the pump will continue to run. Although the Under Set Point LED will turn on immediately whenever the temperature is out range, the alarm relay is disabled for 30 minutes after start-up or after a change in set point. Pressing the Alarm Reset button will reset this fault.

## Pump On



The Pump On LED will be illuminated whenever the pump is running. If the pump is shut off due to a safety, the Pump On LED will turn off. The Start button must be pressed in order to restart the pump.

## Compressor On



The Compressor On LED will be illuminated whenever the compressor is running. The Compressor On LED will cycle on and off with the compressor. The compressor will not come on unless the pump is already running and the To Process temperature is above the Set Point temperature.

*Note: During normal operation, the compressor may cycle on and off. An internal anti-cycle time delay will not allow the compressor to restart for 2.5 minutes after it has cycled off. For air cooled units the fans or blowers will cycle off with the compressor.*

## Partial Load



The Partial Load LED will be illuminated whenever the microprocessor energizes the hot gas bypass solenoid valve. This valve is cycled in order for the chiller to maintain a constant To Process temperature even when there is only a partial load.

The longer that this LED stays on, the more unused excess capacity is available from the chiller. If the Partial Load LED stays off, the chiller is fully loaded by the heat from the process. If the Partial Load LED stays on, the chiller has a very small load on it from the process. If this low load condition persists, the To Process temperature may begin to drop below the Set Point temperature, and when it reaches 5°F (3°C) below the Set Point temperature, the compressor will cycle off. The compressor will come back on when the To Process temperature rises back up to the Set Point temperature and the anti-cycle 2.5 minute time delay relay has timed out.

### Water Make-Up



This LED is nonfunctional on standard units and will only be activated only if the Water Make-Up option has been purchased. When the water level in the reservoir drops below the lower limit of the float switch, the water make-up solenoid valve is opened and the Water Make-Up LED is illuminated. When the water level rises to the upper limit of the float switch, the water make-up solenoid is closed and the Water Make-Up LED turns off. The microprocessor will also close the water make-up solenoid valve if it has been open for 10 minutes. This is done to help prevent further problems if a water leak has developed in the system. If this occurs, the Water Make-Up LED turns off and the Low Water Level LED remains illuminated.

### Low Water Level



This LED is nonfunctional on standard units and will only be active if the Low Water Level option or the Water Make-Up option has been purchased. When the water level in the reservoir drops below the lower limit of the float switch, the Low Water Level LED is illuminated. When the water level rises to the upper limit of the float switch, the Low Water Level LED will shut off.

### High Water Temperature



The High Water Temperature LED will be illuminated if the To Process temperature rises more than 10°F (or 5°C) above the Set Point temperature. The High Water Temperature LED will turn off when the water temperature is less than 10°F (or 5°C) above the Set Point temperature. This fault will not stop operation of the chiller.

### Probe Fault



The Probe Fault LED will illuminate if the signal from the thermocouple is out of tolerance. This fault will also shut off the compressor and the pump. Pressing the Alarm Reset button will reset this alarm.

### Changing Temperature Display Scale

This unit was shipped to display temperatures in either °F or °C. The following step can be followed to determine what temperature scale is in use and will provide instructions as to how to change from one scale to another.

1. Disconnect main power.
2. Open the control panel and switch DIP switch #3 to the on position and close control panel.
3. Reconnect main power.
4. With the power connected and the control power off, hold down the Stop button. While holding the Stop button down, press the Power button. When the controller illuminates, release both buttons.
5. The To Process display will read "Unt". The Set Point display will show either "F" or "C" depending on the current display units selected. If "F" is displayed the temperature display is in °F mode. If "C" is displayed the temperature display is in °C mode.
6. To change from °F to °C press the Lower Set Point Temperature button. To change from °C to °F press the Raise Set Point Temperature button.
7. The Set Point display now indicates the desired display units.

8. Press and release the Start button to store the new selection into the controller memory.
9. Press and release the Power button once to exit the function. Press and release the Power button again to restore controller power.
10. Disconnect main power.
11. Open the control panel and switch DIP switch #3 to the off position and close control panel.
12. Reconnect main power.

The unit is now set and will remain set with the selected temperature scale until the above steps are repeated.

## Diagnostic Error Codes

Several different error codes may be displayed on the digital readouts labeled To Process and Set Point. Most of the possible error codes indicate some type of failure in the microprocessor controller. Below is a list of the error codes. If there are any error codes other than the one listed below, try to reset the unit by shutting the power off and then turning it back on. If this does not work, make a note of the error code and contact our Customer Service Department for further assistance.

**Table 7 - Diagnostic Error Codes**

Error	Description	Cause/Corrective Action
Pr Off	Brown Out Indication	The Pr Off code will be indicated on the display if the chiller is running and main power is discontinued or drops more than 10% below the normal operating voltage, the unit will shut down and the Pr OFF fault will be indicated on the digital displays. Pressing the Power button will clear this fault condition.
101	EEPROM Failure	Controller requires servicing. Contact Manufacturer for repair or replacement.
102	A/D Converter Failure	Controller requires servicing. Contact Manufacturer for repair or replacement.
103	Controller serial bus failure	Controller requires servicing. Contact Manufacturer for repair or replacement.
105	CJC Error	Controller requires servicing. Contact Manufacturer for repair or replacement.
109	Unused memory byte changed	Controller requires servicing. Contact Manufacturer for repair or replacement.
110	Device or communication configuration change or invalid	Controller requires servicing. Contact Manufacturer for repair or replacement.
111	Fixed parameter associated with range invalid	Controller requires servicing. Contact Manufacturer for repair or replacement.
112	Setpoint out of temperature range	Controller requires servicing. Contact Manufacturer for repair or replacement.
113	RAM hardware failure	Controller requires servicing. Contact Manufacturer for repair or replacement.
114	Invalid device configuration	Controller requires servicing. Contact Manufacturer for repair or replacement.
117	Invalid program counter	Controller requires servicing. Contact Manufacturer for repair or replacement.
118	Infinite software loop detect	Controller requires servicing. Contact Manufacturer for repair or replacement.
119	Data direction register failure	Controller requires servicing. Contact Manufacturer for repair or replacement.
120	Communication data register failure	Controller requires servicing. Contact Manufacturer for repair or replacement.
121	Timer data register failure	Controller requires servicing. Contact Manufacturer for repair or replacement.
122	Hardware watchdog data register failure	Controller requires servicing. Contact Manufacturer for repair or replacement.
123	Option data register failure	Controller requires servicing. Contact Manufacturer for repair or replacement.
125	Jumper for temperature controller missing	The Err 125 fault code will be indicated on the digital displays if the jumper is loose or missing on the control circuit board.
126	Pump overload on chiller	The Err 126 fault code will be indicated on the digital displays if the pump overload has tripped. In order to reset this fault; press the Alarm Reset button after resetting the pump overload inside the electrical enclosure.
127	Compressor overload on chiller	The Err 127 fault code will be indicated on the digital display if the internal compressor motor winding thermostat or the external compressor motor overload has tripped. This fault will also shut off the pump. The internal compressor motor winding thermostat will automatically reset when the temperature drops back into the normal operating range. The external compressor motor overload must be manually reset. The compressor motor overload is located inside the electrical enclosure. Once the internal compressor motor winding thermostat resets and/or the external compressor overload has been reset, press the Alarm Reset button to reset the fault.
128	Chiller high temperature safety	The Err 128 fault code will be indicated on the digital displays if the chiller has been shut off due to the high temperature safety. This safety will shut off both the pump and compressor. This safety is triggered if the To Process temperature rises more than 10°F (5.5°C) above the maximum operating temperature for that particular chiller. The maximum operating temperature for each chiller is noted on the nameplate. The To Process temperature must be over the limit for three minutes before this safety will be triggered, and the fault is defeated for a period of thirty minutes from the time the Start button is pressed or the Set Point temperature is changed. Pressing the Alarm Reset button will reset this fault.
129	Input Contact Chatter	

# Control Options

---

## Return Water Temperature Display

This option allows the To Process digital display to indicate To Process or Return Water temperatures. To view the Return Water temperature, hold down the Lower Set Point Temperature and Raise Set Point Temperature buttons simultaneously. Once the buttons are released, the display will return to the To Process temperature.

## Remote On/Off Contacts

This option allows the unit to be turned on and off via a remote contact closure. Two terminals are provided in the control panel to be wired to a remote contact closure device. Switching the contacts from open to close simulates pressing the Start button on the control panel. Switching the contacts from closed to open simulates pressing the Stop button. Please note that the Remote On/Off contacts are nonfunctional until the Power button has been depressed and the control circuit has been energized. This option also includes a remote/local toggle switch that allows the operator to disable the remote contacts for safety purposes while the unit is being serviced.

**Note: Do not introduce any external voltage to these contacts as this will result in damage to the microprocessor, which will not be covered by the warranty.**

## Remote Alarm Contacts

This option includes a set of dry (no voltage induced by chiller), normally open contacts that will close when there is an alarm condition. Refer to Table 6 for the Microprocessor Control Fault Logic to determine which faults will trigger the Remote Alarm contacts. The contacts will reopen by clearing the fault or by pressing the Alarm Silence button.

## Alarm Horn

This option includes an alarm horn that will be activated by certain faults. Refer to Table 6 for the Microprocessor Control Fault Logic to determine which faults will trigger the Alarm Horn. The Alarm Horn will be silenced by clearing the fault or by pressing the Alarm Silence button. If this option is selected in conjunction with the remote control panel, the Alarm Horn will be mounted on the chiller and not the remote control panel.

## Remote Control Panel

This option removes the display and control buttons from the chiller and places them in a small hand-held NEMA-1 enclosure. Included with this option is a 50 foot (15 M) cable to connect the controller and the chiller. All control functions are available to the operator at the location of the remote panel and no control functions are available at the location of the chiller.

## SPI Communications

This option provides an RS-485 communication port located below the control panel on the front of the chiller. The serial communications will be multi-drop, half duplex, SPI 3.01 compatible and will allow the unit to communicate with another piece of equipment that also has SPI protocol capabilities.

The following SPI communications are supported by the microprocessor: process temperature set point, high temperature deviation, low temperature deviation, process status, to process temperature

The microprocessor is designed to accept inputs and deliver outputs according to SPI protocol. There must also be a computer or another piece of equipment that is equipped with the SPI protocol in order for the communications from the chiller to be of any use. The programming of this computer and/or other equipment is not the responsibility of the manufacturer.

**Note: The manufacturer is not responsible for SPI protocol programming beyond what is included in the microprocessor controller.**

When the SPI option is purchased, there is a second set of DIP switches included on the back of the main control panel. This set of DIP switches is labeled "COMM". All DIP switch adjustments that follow are to be made on the COMM set. Do not adjust any DIP switches on the CONFIG set.

**Note: All DIP switch changes must be made with power disconnected.**

In order to activate the SPI protocol, DIP switch #8 must be set to the "On" position. To deactivate the SPI communication, set DIP switch #8 to the "Off" position.

If more than one piece of equipment is going to be on the same communications network, the base address will have to be changed so that each unit has a unique address. This is done by changing one or more of the DIP switches to the "Off" position. The base address is 32 decimal. Changing these switches causes the following address change.

- DIP Switch 1 OFF adds one to base address
- DIP Switch 2 OFF adds two to base address
- DIP Switch 3 OFF adds four to base address
- DIP Switch 4 OFF adds eight to base address
- DIP Switch 5 OFF adds sixteen to base address

The BAUD rate can be adjusted to the appropriate setting by using the information found in Table 8.

**Table 8 - SPI Baud Rate Adjustment**

BAUD Rate	DIP Switch #6	DIP Switch #7
1200	ON	ON
2400	Off	ON
4800	ON	Off
9600	Off	Off

## Chiller Operation

---

### Coolant Circuit

The pump draws coolant from the reservoir and circulates it to the process and returns it to the evaporator. It is in the evaporator where the heat is transferred from the coolant to the refrigerant. Adjusting the amount of heat transferred in the evaporator controls the temperature of the coolant being delivered to the process.

There is a Freezestat sensor and Flow Switch in the coolant circuit to serve as safety controls that are connected to the microprocessor. There is also a thermocouple to sense the temperature of the coolant being delivered to process and communicates this temperature to the microprocessor.

A small coolant bypass line tees off of the manifold between the flow switch and the process connection. This line allows the chiller to operate with sufficient flow through the evaporator even if the flow is restricted or completely shut off through the process. There is a ball valve located in this line that can be adjusted depending on how much flow is required by the process.

*Note: Closing this valve off too far may result in a situation that could damage components in the chiller. The main purpose of the bypass line is to avoid deadheading of the pump and reduce the possibility of an evaporator freeze-up.*

### Refrigerant Circuit

The heat that is transferred in the evaporator from the coolant to the refrigerant is used to change the state of the refrigerant from a liquid to a gas. After leaving the evaporator, the refrigerant passes to the compressor.

The compressor is the heart of the refrigeration circuit. It takes the cool, low-pressure gas entering the compressor and compresses it, which creates the hot, high-pressure gas that exits the compressor. Since the compressor is not 100% efficient, some extra heat is added to the refrigerant as it is being compressed.

The hot, high-pressure gas that exits the compressor is delivered to the condenser. In the condenser, the heat is transferred from the refrigerant into the air or water that is passing through the condenser. As the heat is transferred, the refrigerant changes from a gas to a liquid. The condenser has been sized to remove the heat from the process load and the heat that was added by the compressor.

After leaving the condenser, the liquid refrigerant passes through the service ball valve, filter drier and sight glass. The filter drier removes any particles or moisture from the refrigerant. The sight glass is used to monitor the stream of liquid refrigerant. The liquid refrigerant then passes through the thermal expansion valve (TXV) which meters the flow into the evaporator where the process starts all over again.

Capacity and temperature control is accomplished with a hot gas bypass system. If the chiller were catering to a partial load from the process, the coolant supply temperature would normally tend to drop. The microprocessor senses this drop in temperature, and opens the hot gas bypass solenoid valve. When this valve is open, some of the hot compressor discharge gas is directed to the inlet of the evaporator instead of going through the condenser. This reduces the chillers cooling capacity and puts an additional heat load on the evaporator, which brings the coolant temperature back up to set point. The microprocessor cycles the hot gas solenoid valve as is needed to maintain the coolant temperature even with loads as low as 10% - 25% of full capacity.

If the process heat load is extremely low, or even nonexistent, the hot gas bypass system may not be able to put enough of a load on the evaporator, and the coolant temperature will begin to drop. When the coolant temperature drops 7°F (3°C) below the set point temperature, the controller will shut the compressor off. When the coolant temperature rises back to the set point temperature, the compressor comes back on. The compressor will remain off for at least two minutes to prevent short cycling.

## Chiller Construction

---

### Compressor

The chiller is equipped with a hermetic scroll compressor. Both the compressor and the motor are encased together and solidly mounted in the cabinet. The compressor is unidirectional and will only pump refrigerant when properly phased. The cool refrigerant suction gas cools the motor windings, and there is an internal thermal overload to protect the windings from overheating. The compressor is lubricated with oil that travels throughout the system with the refrigerant.

### Air Cooled Condenser

The condenser is provided on all air cooled condenser models and are constructed of heavy gauge copper tubing and aluminum fins for maximum heat transfer capabilities. The condenser has been generously sized so the chiller can operate with full cooling capacities in ambient air temperatures of up to 95°F (35°C). When the ambient air temperatures are above 95°F (35°C) the chiller will lose approximately 1% of its cooling capacity per 1°F (0.5°C) above 95°F (35°C). The chiller should be able to operate with ambient temperatures of up to 110°F (43°C).

The fans or blowers draw cool air through the condensers and discharges warm air out the top of the cabinet. Units equipped with condenser fans are designed to draw sufficient air through the chiller as long as there are no obstructions. The fans are not designed to draw air through ductwork or discharge air through ductwork. The discharge air will be approximately 35°F (20°C) warmer than the intake air. Units equipped with blowers are not designed to draw air in through ductwork on the intake side; however, they are designed for discharging air through ductwork on the exhaust. Refer to the Suggested Ductwork drawing at the back of this manual.

### Water Cooled Condenser

The water cooled condenser is provided on all water cooled models and is constructed of a steel shell, removable epoxy coated cast iron end plates, and enhanced copper tubes. The condenser water passes through the copper tubes, while the refrigerant passes around the tubes, on the shell side.

### Condenser Water Regulating Valve

A condenser water regulating valve is provided on all water cooled models. This valve is located in the condenser water piping at the outlet of the condenser. It regulates the flow of water through the condenser in order to maintain the high-pressure side of the refrigeration circuit. This valve is set at the factory and should only be adjusted by a qualified refrigeration technician. The valve only passes as much water as is required to maintain the refrigerant pressure, so less water will be required if the water temperature is lower than the design 85°F (29°C).

*Note: The condenser water regulating valve may not completely shut-off water flow when the chiller is not operating. If flow must be completely stopped for any reason, a shut-off valve (manufactured by others) must be used. Make sure the shut-off valve is reopened before restarting the chiller.*

### Condenser Remote Air-Cooled

A remote air cooled condenser is provided with all remote air cooled condenser models. The remote air-cooled condenser has a copper tube and aluminum fin coil with multiple fans. The refrigerant passes through the copper tubes, while the air passes over the fins. The condenser supplied is equipped to vary the header fan(s) speed and operate the remaining fans as

needed to control the refrigerant discharge pressure under varying ambient and chiller loading conditions. Please see the air-cooled remote condenser installation instructions for proper mounting and connection of the condenser.

## **Evaporator**

The evaporator is constructed of stainless steel plates and copper brazing. The refrigerant passes between every other set of plates, while the coolant flows on the other side of the plates in the opposite direction.

## **Thermostatic Expansion Valve**

This valve (referred to as the TXV) separates the high pressure/high temperature side of the refrigeration circuit (the condenser side) from the low pressure/low temperature side of the refrigeration circuit (the evaporator side). The TXV maintains constant superheat at the evaporator outlet, regardless of process load, by precisely metering the amount of refrigerant into the evaporator. Superheat is the difference between the saturated evaporative temperature and the actual measured temperature at the TXV sensor bulb. The superheat is factory set for 10°F to 12°F (5°C to 6°C) and should never exceed 15°F (8°C). Only a trained refrigeration technician should adjust this valve.

## **Refrigerant Sight Glass**

The refrigerant sight glass is located in the liquid line immediately ahead of the expansion valve. It allows the operator or service technician to observe the flow of liquid refrigerant. Prolonged periods of foaming in the sight glass may indicate a low refrigerant condition or a restriction in the liquid line.

*Note: Occasional bubbling in the sight glass may occur at a time when load conditions are changing and the thermostatic expansion valve is adjusting to the new conditions. This momentary occurrence is a result of normal chiller operation.*

The sight glass can also be used to check if there is moisture in the refrigeration system. If there is moisture in the system, the green dot in the center of the sight glass will turn yellow. If this occurs, the chiller should be serviced immediately.

## **Refrigerant Filter Drier**

The filter drier is located in the liquid line between the condenser and the refrigerant sight glass. It is designed to remove any moisture and/or foreign matter that may have gotten into the refrigerant stream. Moisture and foreign matter can cause serious damage to the components of a refrigeration system. For this reason, it is important that the chiller be equipped with a clean filter drier. Replace the filter drier if any of the following conditions occur.

1. The refrigeration system is opened to the atmosphere for repairs or maintenance.
2. Moisture is indicated in the sight glass (the green dot has changed to yellow).
3. An excessive pressure drop develops across the filter drier. This is indicated by a significant temperature difference between the filter inlet and outlet.

## **Pressure Relief Valve**

The pressure relief valve is located in the liquid line after the condenser. It is designed to relieve refrigerant pressure under severe conditions in order to protect the refrigeration circuit components from damage.

## **Hot Gas Bypass Valve**

This valve is located in the refrigerant line that runs from the compressor discharge to the evaporator inlet. It is designed to artificially load the chiller when the chiller is catering to a partial load from the process. This is accomplished by directing some of the hot compressor discharge gas directly back into the evaporator instead of going through the condenser. The microprocessor controller controls the amount of hot gas used. Eliminating cycling of the compressor is extremely desirable as it significantly extends its lifetime expectancy.

## Reservoir

The reservoir is mounted to brackets inside the cabinet. The reservoir is made of polyethylene and is fully insulated. A level glass is included so the coolant level can be observed. There is a removable cover on the top of the reservoir. During chiller operation the reservoir should be at least half full. For most installations the reservoir has sufficient capacity to handle coolant drain back from the process equipment which occurs during chiller shut down. For installations with overhead piping runs of over 90 feet (27 M) special precautions will have to be made during installation (see Installation Section, Figure 1).

*Note: The reservoir cannot be pressurized. Modifications to the chiller that would result in pressurization of the reservoir will void the warranty.*

## Coolant Pump

The close-coupled centrifugal pump is equipped with a mechanical seal and is constructed of stainless steel. The pump is factory tested for the specified operating conditions. The pump motor meets NEMA specifications and industry standards.

## Pressure Gauge

A pressure gauge is mounted on the back panel of the chiller. This gauge displays the pressure of the coolant at the discharge of the pump. It can be used to determine the approximate point on the pump curve in which the pump is operating.

## Y-Strainer

A Y-strainer with a 20-mesh screen is installed in the water line to help protect the evaporator passages from becoming clogged.

## Fan Cycling Controls

This section only applies to air cooled chillers. The fan cycling controls are designed to turn one condenser fan or blower on and off in order to maintain a minimum compressor discharge refrigerant pressure. During normal operation, the fan or blower will cycle on and off based upon the process heat load and ambient air conditions.

## High Refrigerant Pressure Switch

The High Refrigerant Pressure switch is designed to limit the compressor discharge pressure within the design parameters of the compressor. The switch is located on the discharge side of the compressor and can be reset by first pressing the manual reset button located on the High Refrigerant Pressure safety switch and then by pressing the Alarm Reset button on the control panel. The setting on this switch is set to cut out at 375 PSIG (26 Kg/cm<sup>2</sup>) for air cooled units or 300 PSIG (21 Kg/cm<sup>2</sup>) for water cooled units.

## Low Refrigerant Pressure Switch

The Low Refrigerant Pressure switch is designed to limit the compressor suction pressure to within the designed parameters of the compressor. The switch is located in the suction side of the compressor and can be reset by pressing the Alarm Reset button on the control panel. The setting on this switch is set to cut out at 35 PSIG (2.5 Kg/cm<sup>2</sup>) and cut in at 60 PSIG (4.2 Kg/cm<sup>2</sup>).

## High Refrigerant Temperature Switch

The High Refrigerant Temperature switch is designed to limit the compressor discharge temperature to within the design parameters of the compressor. The switch is located on the discharge side of the compressor and can be reset by pressing the Alarm Reset button located on the control panel. The switch is set to cut out at 225°F (107°C).

## Freezestat

The freezestat control is an electronic thermostat that senses the coolant temperature separately from the microprocessor controller. This safety is designed to limit the temperature of the coolant leaving the evaporator and prevent possible freeze-up situations. This control should be set 10°F (5°C) below the minimum coolant supply temperature, and there should be a sufficient glycol concentration for 10°F (5°C) below the freezestat setting.

*Note: It is critical that the freezestat is set properly and that there is sufficient glycol in the system to correspond with the freezestat setting. Freeze-ups can cause extensive damage to several components in the chiller, and the warranty does not cover repairs required due to a freeze-up.*

The Freezestat is located inside the main electrical enclosure. If the chiller shuts down due to the Freezestat, the Alarm Reset button on the control panel must be pressed before the chiller can be restarted.

## Coolant Flow Switch

This switch is located in the water piping before the evaporator inlet. It is designed to shut the unit down if there is insufficient coolant flow through the evaporator. The switch is adjustable; however, no adjustments should be made without prior approval from the factory. If the chiller shuts down due to low coolant flow, pressing the Start button on the control panel can restart it. This switch is disabled for 20 seconds after the Start button is pressed so that the pump can develop flow and make the switch.

## Automatic Water Make-Up (Optional)

With this option, a water supply can be connected to the chiller so that the water level in the reservoir is automatically maintained. When the water level in the reservoir drops below the low level on the float switch, a solenoid valve will be opened to allow fresh water into the system. When the water level reaches the high level on the float switch, the solenoid valve is closed.

*Note: This option is not normally recommended for systems that depend on a glycol solution to prevent freeze-ups. Automatic water make-up may cause reduction of the glycol concentration, which may result in an evaporator freeze-up.*

## Upgraded Pumps (Optional)

The standard pumps that have been selected for each size chiller will meet the requirements of most applications; however, in certain instances, larger pumps may be required to provide the desired flow and pressure for a specific application. The horsepower of the pump will be indicated on the chiller nameplate.

## Preventive Maintenance

---

Once your portable chiller has been placed into service, the following maintenance procedures should be adhered to as closely as possible. The importance of a properly established preventive maintenance program cannot be overemphasized. Taking the time to follow these simple procedures will result in substantially reduced downtime, reduced repair costs, and an extended useful lifetime for the chiller. Any monetary costs of implementing these procedures will almost always more than pay for it.

To make this as simple as possible, a checklist should be prepared which lists the recommended service operations and the times at which they are to be performed. At the end of this section we have included a checklist that can be used for this purpose. Notice that there are locations for voltage readings, amperages, etc. so that they can be monitored over time. With this information, maintenance personnel may be able to correct a potential problem before it causes any downtime. For best results, these readings should be taken with a full heat load from process, preferably with similar operating conditions each time. The following is a list of suggested periodic maintenance.

### Once a Week

1. (Air Cooled Units Only) Check the surface of the air cooled condenser coil for dirt and debris. To clean, rinse thoroughly with water. Mild detergent can be used to remove smoke and or grease stains.
2. Check to make sure that the To Process temperature is maintained reasonably close to the Set Point temperature. If the temperature stays more than 5°F (3°C) away from the set point, there may be a problem with the chiller. If this is the case, refer to the Troubleshooting Chart or contact the Customer Service Department.
3. Check the pump discharge pressure on the gauge on the back panel of the chiller. Investigate further if the pressure starts to stray away from the normal operating pressure.
4. Check the coolant level in the reservoir. Replenish if necessary making sure to take proper precautions to maintain the appropriate glycol concentration.
5. Check coolant circulation pump for leaks in the seal area. Replace pump seal if necessary.
6. Check refrigerant sight glass for air bubbles or moisture indication. If the sight glass indicates that there is a refrigeration problem, have the unit serviced as soon as possible.

## **Once a Month**

7. With the main disconnect shut off and locked out, check the condition of electrical connections at all contactors, starters and controls. Check for loose or frayed wires.
8. Check the incoming voltage to make sure it is within 10% of the design voltage for the chiller.
9. Check the amp draws to each leg of the compressor, (fans or blowers on air cooled units) and pump to confirm that they are drawing the proper current.

## **Every Three Months**

10. Units are equipped with a Y-strainer between the return connection and the evaporator inlet. The strainer basket should be removed and cleaned if necessary. This may be required more often if contaminants can easily get into the process water.
11. Have a qualified refrigeration technician inspect the operation of the entire unit to ensure that everything is operating properly. Have condenser cleaned out if necessary.

# Preventive Maintenance Checklist

Model # \_\_\_\_\_ Serial # \_\_\_\_\_

Maintenance Activity	Week Number												
	1	2	3	4	5	6	7	8	9	10	11	12	13
Date													
Clean Condenser Coil and Inlet Filter (air cooled units)													
Temperature Control													
Pump Discharge Press.													
Coolant Level													
Glycol Concentration													
Pump Seal													
Refrigerant Sight Glass													
Electrical Connections													
Incoming Voltage													
Compressor L1 Amps													
Compressor L2 Amps													
Compressor L3 Amps													
Pump L1 Amps													
Pump L2 Amps													
Pump L3 Amps													
Fan or Blower A L1 Amps													
Fan or Blower A L2 Amps													
Fan or Blower A L3 Amps													
Fan or Blower B L1 Amps													
Fan or Blower B L2 Amps													
Fan or Blower B L3 Amps													
Clean Y-Strainer													
Refrigerant Circuit Check													
Refrigerant Suction Pressure													
Refrigerant Discharge Pressure													
Refrigerant Superheat													

# Troubleshooting

Problem	Possible Cause	Remedy
Compressor will not start	Compressor overload	Check supply voltage, amperage of each leg, contactor and wiring, overload set point
	Compressor contactor	Replace if faulty
	Microprocessor control board	Replace if faulty
	Compressor failure	Contact Customer Service Department for assistance
Pump will not start	Pump overload	Check supply voltage, amperage of each leg, contactor and wiring, overload set point
	Pump contactor	Replace if faulty
	Microprocessor control board	Replace if faulty
	Pump failure	Replace if faulty
Low refrigerant pressure	Low refrigerant charge	Contact refrigeration service technician
	Refrigerant leak	Contact refrigeration service technician
	Low refrigeration pressure sensor	Check for proper range, replace if faulty
	Microprocessor control board	Replace if faulty
High refrigerant pressure	Dirty air filters (air cooled units only)	Clean filters
	Air flow obstruction (air cooled units only)	Make sure chiller is installed in accordance with recommendations in this manual
	High ambient air temperature (air cooled units only)	Ambient temperature must be reduced below 110°F (43°C)
	Condenser fan motor (air cooled units only)	Replace if faulty
	Condenser fan cycling control (air cooled units only)	Confirm proper operation, replace if faulty
	Plugged condenser (water cooled units only)	Clean out tubes
	Insufficient condenser water flow (water cooled units only)	Make sure chiller is installed in accordance with the recommendations of this manual
	High condenser water temperature (water cooled units only)	Condenser water temperature must be reduced below 100°F (38°C)
	Condenser water regulating valve	Check setting, replace if faulty
	Refrigerant circuit overcharged	Contact refrigeration service technician
	High refrigerant pressure sensor	Replace if faulty
Microprocessor control board	Replace if faulty	
Freezestat	Low flow through evaporator	Adjust flow to proper level
	Freezestat control module	Check for proper setting, replace if faulty
	Microprocessor control board	Replace if faulty
	Freezestat sensor	Replace if faulty
Low pump discharge pressure	Pump running backwards	Switch 2 legs of the incoming power
	Pump pressure gauge	Replace if faulty
	Pump failure	Replace if faulty
	Excessive flow	Reduce flow
High pump discharge pressure	Closed valves in process piping	Open valves
	Obstruction in piping or process	Remove obstruction
	Clogged Y-strainer	Clean strainer
	Pressure gauge	Replace if faulty
Erratic temperature control	Low coolant flow through evaporator	Adjust flow to proper level
	Intermittent overloading of chiller capacity	Check to make sure chiller is properly sized for process load
	Hot gas bypass valve	Contact refrigeration service technician
	Microprocessor control board	Replace if faulty
	Thermocouple	Replace if faulty
Insufficient cooling (temperature continues to rise above set point)	Process load too high	Check to make sure chiller is properly sized for process load
	Coolant flow through evaporator too high or too low	Adjust flow to proper level
	Insufficient condenser cooling	See "High Refrigerant Pressure"
	Hot gas bypass valve stuck open	Contact refrigeration service technician
	Refrigeration circuit problem	Contact refrigeration service technician
	Microprocessor control board	Replace if faulty
Thermocouple	Replace if faulty	

# Charts & Pump Curves

**Table 9 - LQ2A08 & LQ2B08 Electrical Specifications**

Model	Pump Hp	Voltage	Compressor		Pump		Condenser Fans/Blowers			Unit MCA
			Qty	RLA	Qty	FLA	Qty	HP	FLA	
LQ2A08	1½	230	1	24.9	1	4.8	2	¾	3.4	43.7
		460		11.2		2.4			1.7	20.8
		575		9.0		2.0			1.7	17.7
	3	230	1	24.9	1	9.0	2	¾	3.4	47.9
		460		11.2		4.5			1.7	22.9
		575		9.0		3.6			1.7	19.3
3 2-stage	230	1	24.9	1	9.0	2	¾	3.4	47.9	
	460		11.2		4.5			1.7	22.9	
	575		9.0		3.6			1.7	19.3	
5	230	1	24.9	1	15.0	2	¾	3.4	53.9	
	460		11.2		7.5			1.7	25.9	
	575		9.0		6.0			1.7	21.7	
5 2-stage	230	1	24.9	1	15.0	2	¾	3.4	53.9	
	460		11.2		7.5			1.7	25.9	
	575		9.0		6.0			1.7	21.7	
7½	230	1	24.9	1	22.0	2	¾	3.4	60.9	
	460		11.2		11.0			1.7	29.4	
	575		9.0		8.8			1.7	24.5	
LQ2B08	1½	230	1	24.9	1	4.8	2	3	9.0	54.9
		460		11.2		2.4			4.5	26.4
		575		9.0		2.0			3.6	21.5
	3	230	1	24.9	1	9.0	2	3	9.0	59.1
		460		11.2		4.5			4.5	28.5
		575		9.0		3.6			3.6	23.1
3 2-stage	230	1	24.9	1	9.0	2	3	9.0	59.1	
	460		11.2		4.5			4.5	28.5	
	575		9.0		3.6			3.6	23.1	
5	230	1	24.9	1	15.0	2	3	9.0	65.1	
	460		11.2		7.5			4.5	31.5	
	575		9.0		6.0			3.6	25.5	
5 2-stage	230	1	24.9	1	15.0	2	3	9.0	65.1	
	460		11.2		7.5			4.5	31.5	
	575		9.0		6.0			3.6	25.5	
7½	230	1	24.9	1	22.0	2	3	9.0	72.1	
	460		11.2		11.0			4.5	35.0	
	575		9.0		8.8			3.6	28.3	

**Notes:**

1. RLA (Rated Load Amps) based on a percentage of the MMTC (Maximum Must Trip Current) as established by the manufacturer in accordance with UL Standard 465.
2. MCA (Minimum Circuit Ampacity) based on 125% of the compressor RLA plus 100% of remaining components FLA plus 1 amp for the control circuit.
3. Voltage Utilization range is: 230 (207 to 254), 460 (414 to 508) and 575 (518 to 635).

**Table 10 - LQ2A10 & LQ2B10 Electrical Specifications**

Model	Pump Hp	Voltage	Compressor		Pump		Condenser Fans/Blowers			Unit MCA
			Qty	RLA	Qty	FLA	Qty	HP	FLA	
LQ2A10	1½	230	1	31.7	1	4.8	2	¾	3.4	52.2
		460		15.8		2.4			1.7	26.6
		575		12.4		2.0			1.7	21.9
	3	230	1	31.7	1	9.0	2	¾	3.4	56.4
		460		15.8		4.5			1.7	28.7
		575		12.4		3.6			1.7	23.5
3 2-stage	230	1	31.7	1	9.0	2	¾	3.4	56.4	
	460		15.8		4.5			1.7	28.7	
	575		12.4		3.6			1.7	23.5	
5	230	1	31.7	1	15.0	2	¾	3.4	62.4	
	460		15.8		7.5			1.7	31.7	
	575		12.4		6.0			1.7	25.9	
5 2-stage	230	1	31.7	1	15.0	2	¾	3.4	62.4	
	460		15.8		7.5			1.7	31.7	
	575		12.4		6.0			1.7	25.9	
7½	230	1	31.7	1	22.0	2	¾	3.4	69.4	
	460		15.8		11.0			1.7	35.2	
	575		12.4		8.8			1.7	28.7	
LQ2B10	1½	230	1	31.7	1	4.8	2	3	9.0	63.4
		460		15.8		2.4			4.5	32.2
		575		12.4		2.0			3.6	25.7
	3	230	1	31.7	1	9.0	2	3	9.0	67.6
		460		15.8		4.5			4.5	34.3
		575		12.4		3.6			3.6	27.3
3 2-stage	230	1	31.7	1	9.0	2	3	9.0	67.6	
	460		15.8		4.5			4.5	34.3	
	575		12.4		3.6			3.6	27.3	
5	230	1	31.7	1	15.0	2	3	9.0	73.6	
	460		15.8		7.5			4.5	37.3	
	575		12.4		6.0			3.6	29.7	
5 2-stage	230	1	31.7	1	15.0	2	3	9.0	73.6	
	460		15.8		7.5			4.5	37.3	
	575		12.4		6.0			3.6	29.7	
7½	230	1	31.7	1	22.0	2	3	9.0	80.6	
	460		15.8		11.0			4.5	40.8	
	575		12.4		8.8			3.6	32.5	

Notes:

1. RLA (Rated Load Amps) based on a percentage of the MMTC (Maximum Must Trip Current) as established by the manufacturer in accordance with UL Standard 465.
2. MCA (Minimum Circuit Ampacity) based on 125% of the compressor RLA plus 100% of remaining components FLA plus 1 amp for the control circuit.
3. Voltage Utilization range is: 230 (207 to 254), 460 (414 to 508) and 575 (518 to 635).

**Table 11 - LQ2A14 & LQ2B14 Electrical Specifications**

Model	Pump Hp	Voltage	Compressor		Pump		Condenser Fans/Blowers			Unit MCA
			Qty	RLA	Qty	FLA	Qty	HP	FLA	
LQ2A14	1½	230	1	62.2	1	4.8	2	¾	3.4	90.4
		460		27.6		2.4			1.7	41.3
		575		22.1		2.0			1.7	34.0
	3	230	1	62.2	1	9.0	2	¾	3.4	94.6
		460		27.6		4.5			1.7	43.4
		575		22.1		3.6			1.7	35.6
3 2-stage	230	1	62.2	1	9.0	2	¾	3.4	94.6	
	460		27.6		4.5			1.7	43.4	
	575		22.1		3.6			1.7	35.6	
5	230	1	62.2	1	15.0	2	¾	3.4	100.6	
	460		27.6		7.5			1.7	46.4	
	575		22.1		6.0			1.7	38.0	
5 2-stage	230	1	62.2	1	15.0	2	¾	3.4	100.6	
	460		27.6		7.5			1.7	46.4	
	575		22.1		6.0			1.7	38.0	
7½	230	1	62.2	1	22.0	2	¾	3.4	107.6	
	460		27.6		11.0			1.7	49.9	
	575		22.1		8.8			1.7	40.8	
LQ2B14	1½	230	1	62.2	1	4.8	2	3	9.0	101.6
		460		27.6		2.4			4.5	46.9
		575		22.1		2.0			3.6	37.8
	3	230	1	62.2	1	9.0	2	3	9.0	105.8
		460		27.6		4.5			4.5	49.0
		575		22.1		3.6			3.6	39.4
3 2-stage	230	1	62.2	1	9.0	2	3	9.0	105.8	
	460		27.6		4.5			4.5	49.0	
	575		22.1		3.6			3.6	39.4	
5	230	1	62.2	1	15.0	2	3	9.0	111.8	
	460		27.6		7.5			4.5	52.0	
	575		22.1		6.0			3.6	41.8	
5 2-stage	230	1	62.2	1	15.0	2	3	9.0	111.8	
	460		27.6		7.5			4.5	52.0	
	575		22.1		6.0			3.6	41.8	
7½	230	1	62.2	1	22.0	2	3	9.0	118.8	
	460		27.6		11.0			4.5	55.5	
	575		22.1		8.8			3.6	44.6	

Notes:

1. RLA (Rated Load Amps) based on a percentage of the MMTC (Maximum Must Trip Current) as established by the manufacturer in accordance with UL Standard 465.
2. MCA (Minimum Circuit Ampacity) based on 125% of the compressor RLA plus 100% of remaining components FLA plus 1 amp for the control circuit.
3. Voltage Utilization range is: 230 (207 to 254), 460 (414 to 508) and 575 (518 to 635).

**Table 12 - LQ2A15 & LQ2B15 Electrical Specifications**

Model	Pump Hp	Voltage	Compressor		Pump		Condenser Fans/Blowers			Unit MCA
			Qty	RLA	Qty	FLA	Qty	HP	FLA	
LQ2A15	3	230	1	62.2	1	9.0	2	2	6.0	99.8
		460		27.6		4.5			3.0	46.0
		575		22.1		3.6			2.4	37.0
	3 2-stage	230	1	62.2	1	9.0	2	2	6.0	99.8
		460		27.6		4.5			3.0	46.0
		575		22.1		3.6			2.4	37.0
5	230	1	62.2	1	15.0	2	2	6.0	105.8	
	460		27.6		7.5			3.0	49.0	
	575		22.1		6.0			2.4	39.4	
5 2-stage	230	1	62.2	1	15.0	2	2	6.0	105.8	
	460		27.6		7.5			3.0	49.0	
	575		22.1		6.0			2.4	39.4	
7½	230	1	62.2	1	22.0	2	2	6.0	112.8	
	460		27.6		11.0			3.0	52.5	
	575		22.1		8.8			2.4	42.2	
10	230	1	62.2	1	28.0	2	2	6.0	118.8	
	460		27.6		14.0			3.0	55.5	
	575		22.1		11.2			2.4	44.6	
LQ2B15	3	230	1	62.2	1	9.0	2	3	9.0	105.8
		460		27.6		4.5			4.5	49.0
		575		22.1		3.6			3.6	39.4
	3 2-stage	230	1	62.2	1	9.0	2	3	9.0	105.8
		460		27.6		4.5			4.5	49.0
		575		22.1		3.6			3.6	39.4
5	230	1	62.2	1	15.0	2	3	9.0	111.8	
	460		27.6		7.5			4.5	52.0	
	575		22.1		6.0			3.6	41.8	
5 2-stage	230	1	62.2	1	15.0	2	3	9.0	111.8	
	460		27.6		7.5			4.5	52.0	
	575		22.1		6.0			3.6	41.8	
7½	230	1	62.2	1	22.0	2	3	9.0	118.8	
	460		27.6		11.0			4.5	55.5	
	575		22.1		8.8			3.6	44.6	
10	230	1	62.2	1	28.0	2	3	9.0	124.8	
	460		27.6		14.0			4.5	58.5	
	575		22.1		11.2			3.6	47.0	

Notes:

1. RLA (Rated Load Amps) based on a percentage of the MMTC (Maximum Must Trip Current) as established by the manufacturer in accordance with UL Standard 465.
2. MCA (Minimum Circuit Ampacity) based on 125% of the compressor RLA plus 100% of remaining components FLA plus 1 amp for the control circuit.
3. Voltage Utilization range is: 230 (207 to 254), 460 (414 to 508) and 575 (518 to 635).

**Table 13 - LQ2A20 & LQ2B20 Electrical Specifications**

Model	Pump Hp	Voltage	Compressor A		Compressor B		Pump		Condenser Fans/Blowers			Unit MCA
			Qty	RLA	Qty	RLA	Qty	FLA	Qty	HP	FLA	
LQ2A20	3	230	1	42.2	1	42.2	1	9.0	2	2	6.0	117.0
		460		18.4		18.4		4.5			3.0	52.9
		575		14.8		14.8		3.6			2.4	42.7
	3 2-stage	230	1	42.2	1	42.2	1	9.0	2	2	6.0	117.0
		460		18.4		18.4		4.5			3.0	52.9
		575		14.8		14.8		3.6			2.4	42.7
5	230	1	42.2	1	42.2	1	15.0	2	2	6.0	123.0	
	460		18.4		18.4		7.5			3.0	55.9	
	575		14.8		14.8		6.0			2.4	45.1	
5 2-stage	230	1	42.2	1	42.2	1	15.0	2	2	6.0	123.0	
	460		18.4		18.4		7.5			3.0	55.9	
	575		14.8		14.8		6.0			2.4	45.1	
7½	230	1	42.2	1	42.2	1	22.0	2	2	6.0	130.0	
	460		18.4		18.4		11.0			3.0	59.4	
	575		14.8		14.8		8.8			2.4	47.9	
10	230	1	42.2	1	42.2	1	28.0	2	2	6.0	136.0	
	460		18.4		18.4		14.0			3.0	62.4	
	575		14.8		14.8		11.2			2.4	50.3	
LQ2B20	3	230	1	42.2	1	42.2	1	9.0	2	3	9.0	123.0
		460		18.4		18.4		4.5			4.5	55.9
		575		14.8		14.8		3.6			3.6	45.1
	3 2-stage	230	1	42.2	1	42.2	1	9.0	2	3	9.0	123.0
		460		18.4		18.4		4.5			4.5	55.9
		575		14.8		14.8		3.6			3.6	45.1
5	230	1	42.2	1	42.2	1	15.0	2	3	9.0	129.0	
	460		18.4		18.4		7.5			4.5	58.9	
	575		14.8		14.8		6.0			3.6	47.5	
5 2-stage	230	1	42.2	1	42.2	1	15.0	2	3	9.0	129.0	
	460		18.4		18.4		7.5			4.5	58.9	
	575		14.8		14.8		6.0			3.6	47.5	
7½	230	1	42.2	1	42.2	1	22.0	2	3	9.0	136.0	
	460		18.4		18.4		11.0			4.5	62.4	
	575		14.8		14.8		8.8			3.6	50.3	
10	230	1	42.2	1	42.2	1	28.0	2	3	9.0	142.0	
	460		18.4		18.4		14.0			4.5	65.4	
	575		14.8		14.8		11.2			3.6	52.7	

**Notes:**

1. RLA (Rated Load Amps) based on a percentage of the MMTC (Maximum Must Trip Current) as established by the manufacturer in accordance with UL Standard 465.
2. MCA (Minimum Circuit Ampacity) based on 125% of the compressor RLA plus 100% of remaining components FLA plus 1 amp for the control circuit.
3. Voltage Utilization range is: 230 (207 to 254), 460 (414 to 508) and 575 (518 to 635).

**Table 14 - LQ2A25 & LQ2B25 Electrical Specifications**

Model	Pump Hp	Voltage	Compressor A		Compressor B		Pump		Condenser Fans/Blowers			Unit MCA
			Qty	RLA	Qty	RLA	Qty	FLA	Qty	HP	FLA	
LQ2A25	3	230	1	62.2	1	42.2	1	9.0	2	2	6.0	142.0
		460		27.6		18.4		4.5			3.0	64.4
		575		22.1		14.8		3.6			2.4	51.8
	3 2-stage	230	1	62.2	1	42.2	1	9.0	2	2	6.0	142.0
		460		27.6		18.4		4.5			3.0	64.4
		575		22.1		14.8		3.6			2.4	51.8
5	230	1	62.2	1	42.2	1	15.0	2	2	6.0	148.0	
	460		27.6		18.4		7.5			3.0	67.4	
	575		22.1		14.8		6.0			2.4	54.2	
5 2-stage	230	1	62.2	1	42.2	1	15.0	2	2	6.0	148.0	
	460		27.6		18.4		7.5			3.0	67.4	
	575		22.1		14.8		6.0			2.4	54.2	
7½	230	1	62.2	1	42.2	1	22.0	2	2	6.0	155.0	
	460		27.6		18.4		11.0			3.0	70.9	
	575		22.1		14.8		8.8			2.4	57.0	
10	230	1	62.2	1	42.2	1	28.0	2	2	6.0	161.0	
	460		27.6		18.4		14.0			3.0	73.9	
	575		22.1		14.8		11.2			2.4	59.4	
LQ2B25	3	230	1	62.2	1	42.2	1	9.0	2	3	9.0	148.0
		460		27.6		18.4		4.5			4.5	67.4
		575		22.1		14.8		3.6			3.6	54.2
	3 2-stage	230	1	62.2	1	42.2	1	9.0	2	3	9.0	148.0
		460		27.6		18.4		4.5			4.5	67.4
		575		22.1		14.8		3.6			3.6	54.2
5	230	1	62.2	1	42.2	1	15.0	2	3	9.0	154.0	
	460		27.6		18.4		7.5			4.5	70.4	
	575		22.1		14.8		6.0			3.6	56.6	
5 2-stage	230	1	62.2	1	42.2	1	15.0	2	3	9.0	154.0	
	460		27.6		18.4		7.5			4.5	70.4	
	575		22.1		14.8		6.0			3.6	56.6	
7½	230	1	62.2	1	42.2	1	22.0	2	3	9.0	161.0	
	460		27.6		18.4		11.0			4.5	73.9	
	575		22.1		14.8		8.8			3.6	59.4	
10	230	1	62.2	1	42.2	1	28.0	2	3	9.0	167.0	
	460		27.6		18.4		14.0			4.5	76.9	
	575		22.1		14.8		11.2			3.6	61.8	

**Notes:**

1. RLA (Rated Load Amps) based on a percentage of the MMTC (Maximum Must Trip Current) as established by the manufacturer in accordance with UL Standard 465.
2. MCA (Minimum Circuit Ampacity) based on 125% of the compressor RLA plus 100% of remaining components FLA plus 1 amp for the control circuit.
3. Voltage Utilization range is: 230 (207 to 254), 460 (414 to 508) and 575 (518 to 635).

**Table 15 - LQ2W08, LQ2R08, LQ2W10 & LQ2R10 Electrical Specifications**

Model	Pump Hp	Voltage	Compressor A		Compressor B		Pump		Unit MCA
			Qty	RLA	Qty	RLA	Qty	FLA	
<b>LQ2W08 LQ2R08</b>	1½	230	1	24.9	-	-	1	4.8	36.9
		460		11.2				2.4	17.4
		575		9.0				2.0	14.3
	3	230	1	24.9	-	-	1	9.0	41.1
		460		11.2				4.5	19.5
		575		9.0				3.6	15.9
3 2-stage	230	1	24.9	-	-	1	9.0	41.1	
	460		11.2				4.5	19.5	
	575		9.0				3.6	15.9	
5	230	1	24.9	-	-	1	15.0	47.1	
	460		11.2				7.5	22.5	
	575		9.0				6.0	18.3	
5 2-stage	230	1	24.9	-	-	1	15.0	47.1	
	460		11.2				7.5	22.5	
	575		9.0				6.0	18.3	
7½	230	1	24.9	-	-	1	22.0	54.1	
	460		11.2				11.0	26.0	
	575		9.0				8.8	21.1	
<b>LQ2W10 LQ2R10</b>	1½	230	1	31.7	-	-	1	4.8	45.4
		460		15.8				2.4	23.2
		575		12.4				2.0	18.5
	3	230	1	31.7	-	-	1	9.0	49.6
		460		15.8				4.5	25.3
		575		12.4				3.6	20.1
3 2-stage	230	1	31.7	-	-	1	9.0	49.6	
	460		15.8				4.5	25.3	
	575		12.4				3.6	20.1	
5	230	1	31.7	-	-	1	15.0	55.6	
	460		15.8				7.5	28.3	
	575		12.4				6.0	22.5	
5 2-stage	230	1	31.7	-	-	1	15.0	55.6	
	460		15.8				7.5	28.3	
	575		12.4				6.0	22.5	
7½	230	1	31.7	-	-	1	22.0	62.6	
	460		15.8				11.0	31.8	
	575		12.4				8.8	25.3	

Notes:

1. RLA (Rated Load Amps) based on a percentage of the MMTC (Maximum Must Trip Current) as established by the manufacturer in accordance with UL Standard 465.
2. MCA (Minimum Circuit Ampacity) based on 125% of the compressor RLA plus 100% of remaining components FLA plus 1 amp for the control circuit.
3. Voltage Utilization range is: 230 (207 to 254), 460 (414 to 508) and 575 (518 to 635).

**Table 16 - LQ2W15, LQ2R15, LW2W20 & LQ2R20 Electrical Specifications**

Model	Pump Hp	Voltage	Compressor A		Compressor B		Pump		Unit MCA
			Qty	RLA	Qty	RLA	Qty	FLA	
<b>LQ2W15 LQ2R15</b>	3	230	1	62.2	-	-	1	9.0	87.8
		460		27.6				4.5	40.0
		575		22.1				3.6	32.2
	3 2-stage	230	1	62.2	-	-	1	9.0	87.8
		460		27.6				4.5	40.0
		575		22.1				3.6	32.2
5	230	1	62.2	-	-	1	15.0	93.8	
	460		27.6				7.5	43.0	
	575		22.1				6.0	34.6	
5 2-stage	230	1	62.2	-	-	1	15.0	93.8	
	460		27.6				7.5	43.0	
	575		22.1				6.0	34.6	
7½	230	1	62.2	-	-	1	22.0	100.8	
	460		27.6				11.0	46.5	
	575		22.1				8.8	37.4	
10	230	1	62.2	-	-	1	28.0	106.8	
	460		27.6				14.0	49.5	
	575		22.1				11.2	39.8	
<b>LQ2W20 LQ2R20</b>	3	230	1	42.2	1	42.2	1	9.0	105.0
		460		18.4				4.5	46.9
		575		14.8				3.6	37.9
	3 2-stage	230	1	42.2	1	42.2	1	9.0	105.0
		460		18.4				4.5	46.9
		575		14.8				3.6	37.9
5	230	1	42.2	1	42.2	1	15.0	111.0	
	460		18.4				7.5	49.9	
	575		14.8				6.0	40.3	
5 2-stage	230	1	42.2	1	42.2	1	15.0	111.0	
	460		18.4				7.5	49.9	
	575		14.8				6.0	40.3	
7½	230	1	42.2	1	42.2	1	22.0	118.0	
	460		18.4				11.0	53.4	
	575		14.8				8.8	43.1	
10	230	1	42.2	1	42.2	1	28.0	124.0	
	460		18.4				14.0	56.4	
	575		14.8				11.2	45.5	

Notes:

1. RLA (Rated Load Amps) based on a percentage of the MMTC (Maximum Must Trip Current) as established by the manufacturer in accordance with UL Standard 465.
2. MCA (Minimum Circuit Ampacity) based on 125% of the compressor RLA plus 100% of remaining components FLA plus 1 amp for the control circuit.
3. Voltage Utilization range is: 230 (207 to 254), 460 (414 to 508) and 575 (518 to 635).


**Table 17 - LQ2W25, LQ2R25, LQ2W30, LQ2R30, LQ2W35, LQ2R35, LQ2W40 & LQ2R40 Electrical Specification**

Model	Pump Hp	Voltage	Compressor A		Compressor B		Pump		Unit MCA
			Qty	RLA	Qty	RLA	Qty	FLA	
LQ2W25 LQ2R25	5	230	1	62.2	1	42.2	1	15.0	136.0
		460		27.6		18.4		7.5	61.4
		575		22.1		14.8		6.0	49.4
	5 2-stage	230	1	62.2	1	42.2	1	15.0	136.0
460	27.6	18.4		7.5		61.4			
575	22.1	14.8		6.0		49.4			
LQ2W25 LQ2R25	7½	230	1	62.2	1	42.2	1	22.0	143.0
		460		27.6		18.4		11.0	64.9
		575		22.1		14.8		8.8	52.2
	10	230	1	62.2	1	42.2	1	28.0	149.0
460	27.6	18.4		14.0		67.9			
575	22.1	14.8		11.2		54.6			
LQ2W30 LQ2R30	5	230	1	62.2	1	62.2	1	15.0	156.0
		460		27.6		27.6		7.5	70.6
		575		22.1		22.1		6.0	56.7
	5 2-stg	230	1	62.2	1	62.2	1	15.0	156.0
460	27.6	27.6		7.5		70.6			
575	22.1	22.1		6.0		56.7			
LQ2W30 LQ2R30	7½	230	1	62.2	1	62.2	1	22.0	163.0
		460		27.6		27.6		11.0	74.1
		575		22.1		22.1		8.8	59.5
	10	230	1	62.2	1	62.2	1	28.0	169.0
460	27.6	27.6		14.0		77.1			
575	22.1	22.1		11.2		61.9			
LQ2W35 LQ2R35	7½	230	1	81.4	1	55.2	1	22.0	180.0
		460		33.6		27.2		11.0	81.2
		575		27.1		24.2		8.8	67.9
	10	230	1	81.4	1	55.2	1	28.0	186.0
460	33.6	27.2		14.0		84.2			
575	27.1	24.2		11.2		70.3			
LQ2W40 LQ2R40	7½	230	1	81.4	1	81.4	1	22.0	206.2
		460		33.6		33.6		11.0	87.6
		575		27.1		27.1		8.8	70.8
	10	230	1	81.4	1	81.4	1	28.0	212.2
460	33.6	33.6		14.0		90.6			
575	27.1	27.1		11.2		73.2			

Notes:

1. RLA (Rated Load Amps) based on a percentage of the MMTC (Maximum Must Trip Current) as established by the manufacturer in accordance with UL Standard 465.
2. MCA (Minimum Circuit Ampacity) based on 125% of the compressor RLA plus 100% of remaining components FLA plus 1 amp for the control circuit.
3. Voltage Utilization range is: 230 (207 to 254), 460 (414 to 508) and 575 (518 to 635).


Figure 2 - 60 Hz Pump Curves



# Drawings

We have prepared a custom set of drawings for your unit and placed them inside the control panel prior to shipment. Please refer to these drawings when troubleshooting, servicing, and installing the unit. If you cannot find these drawings or wish to have additional copies, please contact our Customer Service Department and reference the serial number of your unit.

**Figure 3 - LQ2B Series Suggested Ductwork Diagram**



# Warranty

---

Thermal Care warrants its equipment to be free from defects in material and workmanship when used under recommended operating conditions.

Thermal Care's obligation is limited to repair (i.e. rewind a motor) or replacement (not adjustment or maintenance), F.O.B. the factory of any parts supplied by Thermal Care within a period as shown below from the date of shipment to the original purchaser.

<b>Model</b>	<b>Parts</b>	<b>Labor<sup>1</sup></b>
SQ, LQ	18 months	12 months
EQ	12 months	12 months
EQR, LQR, SQR(remote condensers)	12 months	12 months <sup>2</sup>
TCW, TSW, TXW	12 months	12 months
TCR, TSR, TXR (remote condensers)	12 months	12 months <sup>2</sup>
Optional Compressor Warranty	5 years	
Chilled Water Systems	See note <sup>3</sup>	12 months <sup>4</sup>
FT or FC Tower Systems	See note <sup>3</sup>	12 months <sup>4</sup>
FT Cooling Tower	12 months (10 years - shell)	
FC Cooling Tower	5 years (10 years - shell)	
RA, RB	(See Warranty Sheet – Form 1-415)	
All other products	12 months	

<sup>1</sup>Continental U.S.A., Canada, and Puerto Rico only.

<sup>2</sup>Refrigerant and any labor associated with its evacuation or replacement are not covered for remote condenser systems.

<sup>3</sup>See individual product listing for parts warranty coverage.

<sup>4</sup>The labor warranty covers all equipment purchased at the same time consisting of a minimum of at least one pumping system and one cooling tower and/or chiller.

This warranty does not cover the cost of labor during overtime hours (after normal working hours or during weekends and holidays). Any cost differential for overtime labor will be the responsibility of the customer. Thermal Care is not responsible for any sales, use, excise or other applicable taxes associated with the replacement of parts under this warranty. This warranty will be voided when, in Thermal Care's opinion, the equipment and/or system has been subject to misuse, negligence or operation in excess of recommended limits, including freezing, or has been altered, and/or repaired without express factory authorization. If equipment is installed in hostile environments, unless such conditions were specified at the time of purchase; or the serial number has been removed or defaced, this warranty shall not apply. This warranty is not transferable.

Under no circumstances shall Thermal Care be liable for loss of prospective or speculative profits, or special, indirect, incidental or consequential damages.

Thermal Care must authorize all warranty service prior to work being performed and have a Thermal Care purchase order issued. All defective parts become the property of Thermal Care and must be returned as advised by Thermal Care.

Thermal Care neither assumes, nor authorizes any person to assume for it, any liability not expressed in this warranty. There is an implied warranty of merchantability and of fitness for that particular purpose; all other implied warranties, and any liability not based upon contract are hereby disclaimed and excluded by this warranty. This warranty is part of the standard conditions and terms of sale of Thermal Care.



7720 N. Lehigh Avenue  
Niles, Illinois 60714-3491  
Phone: (847) 966-2260  
(888) 828-7387  
Fax: (847) 966-9358

Email: [info@thermalcare.com](mailto:info@thermalcare.com)  
[www.thermalcare.com](http://www.thermalcare.com)  
**Customer Service**  
Phone: (847) 966-2636  
Fax: (847) 966-2906

Warranty Form 1-410.11  
Effective 4/9/07

## Notes

---

---

**Thermal Care, Inc.**  
7720 North Lehigh Ave.  
Niles, IL 60714-3491  
www.thermalcare.com

**New Equipment Sales**  
Phone (847) 966-2260  
Fax (847) 966-9358  
Email info@thermalcare.com

**Customer Service**  
Phone (847) 966-2636  
Fax (847) 966-2906  
Email service@thermalcare.com

**Parts**  
Phone (847) 966-8560  
Fax (847) 966-6065  
Email tcparts@thermalcare.com